

# HOW TO MOUNT ULTIMA SOFT IN THE FLEX RING "SLÄGGÖ"



The Ultima Soft Dry Glove System parts. Two suit rings, two glove rings, two cover rings, two O-rings, two equalization tubes, a tool and glove ring lubricant.



**1**

Make sure the Spanner Ring is mounted correctly with the ridge in the bottom. The ring has to be mounted at all times when using the Ultima Soft DGS.



**2**

Mount the seal on the ring. Pull it evenly until the ridge on the seal and the ridge on the suit ring are close together.



**3**

Turn the silicone Wrist Seal inside out and make sure it is clean.



**4**

Apply a waterbased lubricant onto the Silicone Seal end, about 2cm wide. Do not use too little, it is important that the whole seal slides easily.



**5**

Push the ring inside the suit approximately 1cm until it stays there. Make sure the seal stays in place. This can be tricky but is easy after some practice.



**6**

Put the Suit Ring in the suit arm carefully.



**7**

Change grip and use both hands on opposite sides of the ring and press hard at the same time until it pops into place. It is important to press evenly so it doesn't slide out of position.



**8**

Check that the seal is properly mounted by pulling and visually inspect the inside.

## HOW TO DISMOUNT



**1**

Use the tool to dismount the ring from the suit. Put in the pointed end with the hook away from the suit, and slowly press apart. There might be necessary to press apart twice with small distance between.



**2**

When the opening is large enough use the hands and bend apart.

**For further information about the ULTIMA Dry Glove System and mounting of the dry glove please see the manual.**